

							
CAM LARGE, CODE: BDB108A	CAM LARGE, CODE: BDB108B	SUCTION HOLDER	JACQUARD GUIDE WHEEL SUPPORT	3 HOLES OF WEFT GUIDE, CODE: AMQF09A	4 HOLES OF WEFT GUIDE	GUIDE STRIPE	FIXED BLOCK
							
PLATE, CODE: EM8017A	SCALE WHEEL, CODE: DDF11A	HANDLE, CODE: ADQF01A	HANDLE	HANDLE, CODE: ELB075A	HOOK, CODE: ADGF01A	SLIDING BLOCK, CODE: A1A184B	SLIDING BLOCK, CODE: ELT003A
							
CLAMP	SEAL, CODE: EDD015A	MIDDLE CAM, CODE: AR50469	CAM, CODE: ALT105B	CAM	CLAMP, CODE: EPS235A	STRING CLAMP	LINING, CODE: ED902A
							
CODE: ADHF03A	CODE: ES104BA	WEFT GUIDE PART	CODE: EH1214A	CODE: FTF0341	CODE: ETF033A	CODE: AM8301B	CODE: AM8301B


							
CODE: AM8301A	WEFT GUIDE COMPLETE	ROCKER ARM, CODE: EPS218A	CODE: ADHF03A	CLAMP, CODE: ADE107A	CODE: EPS214A	CODE: ELT012A	CODE: EDQ018A
							
CODE: EPS029A	CODE: EPS118A	CODE: EPS043A	CODE: EPE007A	CODE: EPS066A	CODE: EDQ014A	CODE: EPS297A	CODE: EDR031A
							
BUSH	CODE: ED8076A	CODE: ED8063A	CODE: ED8062A	CODE: EPS007A	CODE: EDR037A	CODE: A1A197A	CODE: EDR038A
							
CODE: ETQ018A	NYLON WASHER	CODE: ED8061A	HANDLE	CODE: ES1013A	CODE: VV10301	CODE: ALTF09A	CODE: EDY012A


							
CODE: A2A046B	CODE: A2A163A	CODE: VC10108	CODE: ALF153A	CODE: EPS286A	CODE: A1A197A	CODE: EDH012A	CODE: EDH005A
							
CODE: ADE104A	CODE: ADE10A	CODE: AMD102B	CODE: AL5105A	CODE: EDF002A	CODE: EDF003A	HQ6020A, ETH002A	CODE: AMF01A
							
CODE: A1A182B	CODE: A10557A	CODE: EDR028A	CODE: EDR018A	CODE: EPS005A	CODE: EDG02A	CODE: EDG027A	CODE: A;BF06A
							
ADAF03A	CODE: EPS006A	CODE: EDG003A	CODE: ADQF01A	CODE: ADQF02A	CODE: AMSF02A	SM92/93 WASTE TAKE-UP DEVICE	

							
CODE: ELB006A	CODE: EM5007A	CODE: ADHF01C	CODE: ED8037A	CODE: ASAF01A	CODE: A1F100A	CODE: C9C1143	CODE: C9C1143
							
CODE: EPS019A	GEAR	EPS229A D15 WITH GROOVE	WITHOUT GROOVE D12	CODE: EPS053A	CODE: ELB098B	CODE: ELB098A	CODE: EDN015C
							
CODE: EDB006A	CODE: ADB104A	GUIDE HOOK ST880	GUIDE HOOK SM93 DOUBLE TYPE	GUIDE HOOK SM93	GUIDE HOOK SM93 DOUBLE, EH31010B	GUIDE HOOK SM93 SINGLE TYPE	CODE: EW3122A
							
CODE: EH3094	CODE: VM11002	SCREW FOR GUIDE HOOK	WASHER	CODE: ED8076A	CODE: EDN004A	CODE: A1A217A	


							
PAPER, RACE BOARD COVERING	BUSHING NYLON SM93 (23.24, 25, 26)	GEAR SM93	CODE: EPS29A	CODE: EDY099A	CODE: EDY104A	CUTTER CAM SM93	DOBBY COVER RH
							
DOBBY COVER LH	CODE: EDC003B	TENSION SHEET, 50 X 54	TENSION SHEET, 50 X 110	LENO DEVICE PART	LENO DEVICE PART	CODE: ADHF04B	OIL LEVER CHECKER
							
LENO DEVICE PART	LENO DEVICE PART	LENO DEVICE PART	LENO DEVICE PART	LENO DEVICE PART	LENO DEVICE NEEDLE	LENO DEVICE PART	
							
LENO DEVICE COMPLETE			CODE: A1A217A			CENTRAL SUPPORT HEALD FRAME	



							
ROLLER	SM 93 CLAMP	UMBRELLA-TYPE UPPER	STERILE TUBE	BRACKET	SUCTION PART	CAM	CAM
							
WASHER	HOOK SM93	BUSHING	COVER	SUCTION PART	SUCTION STEEL TUBE	CODE:ADY301C	CODE: EDY035A
							
SUPPORT WHEEL	CODE: AL3F01A	CODE: AL5F01A	GEAR	CODE: ADAF03A	CODE: AIL042A	GEAR	CODE: EDD002A
							
CODE: ZDP013A	CODE: AIF938A, EPS221A, EPS152A	FILTER	CODE: ADH202D SM92/93		CODE: BN7F32A	CODE: BN7F33A	WEFT GUIDER HOOK


							
TOOTHED STRIP RH	TOOTHED STRIP SMALL	CODE: Z140805	CODE: ADYF26A	CODE: ADYF23A	CODE: EH3037B	CODE: A1F093A	CODE: ADHF04B
							
SM93 GUIDE HOOK	CODE: CAC8502	CODE: A1F153A	RH SUPPORT	LH SUPPORT	OIL COVER	CODE: VG10518	BEARING
							
BRACKET	WASHER	CODE: CGR8492	ADB104A	OIL PLATE	SEPARATOR	SEPARATOR	SEPARATING PIECE
							
BRACKET BIG	BRACKET SMALL	CODE: EDF001B	VERY BIG BRACKET		SPRING SELECTOR	CODE: CAC7904	CODE: EDB003C


							
CODE: EDA081A	BEARING	CODE: A1FE90A	CODE: EPE001A	CODE: CFR585A-1	CODE: CFR100A	PARTING SLIP	CODE: CFR756A
							
CODE: CFR585A-2	OIL WATCH	ELN005A	ESH002A	ESP9024A	EM5007A	AM5F02A	ED8038A
							
CODE: ED8037A	CODE: AD8121A	HOLDER	AC/2S MIDDLE BLADE RH	CODE: R62077Y	AC/2S MIDDLE BLADE RH SMALL	AC/2S MIDDLE BLADE LH SMALL	CODE: EWM023A
							
CODE: ADY107C	CODE: ADY106B	CODE: AIL596A	CODE: AIL598B	CODE: R62076Y	AC/2S MIDDLE BLADE LH	GEAR	GUIDE THREAD




							 Z
WASHER	COVER	SEPARATOR	WASHER SMALL	WASHER BIG	CODE: ZLB098B	CMZ081A	CODE: A3A027B
							
BEARING SEAT	CODE: EDN002A	CODE: T0140006		CODE: ELS002A		CODE: EDC003B	WASHER
							
D90 OIL PLATE	D110 OIL PLATE	CODE: ALF153A	CODE: EDB061A	CODE: EPS036	END CAP	CODE: CGR5505	CODE: EDC017A
							
CODE: ALT106A	CODE: ALT107A	CODE: ELT003A	CODE: AIAI84B	CODE: ALT103A	CODE: ALT104A	CODE: ELT015A	CODE: EWM023A

							
CODE: ALTF09A	CODE: EPE007A	CODE:ELT012A	CODE: ECS0101	CODE:EMF004A	CODE: ELT009A	CODE:VV16037	CODE: VV16015
							
SHAFT	CODE: ELT004A	WASHER	CODE: VA11114	CODE: VA11107	CODE:CLT107A	CODE: VV22011	CODE: VS11108
							
CODE: VD14003	CODE: VD13007	CODE: VD13001	CODE: VM11009	CODE: VM11004	CODE:VM11002	CODE: VV19023	CODE: E3Q028A
							
CODE: HDY062B	CODE: HDY108A	CODE: HDY094A	CODE: HDY093A	CODE: EDY003D	CODE: HDY012C	CODE: HDY011A	CODE: EDY248B





							
CODE: HDY054A	CODE: HDY097B		CODE: EDY210B	CODE: HDY009A	CODE: EDY132B	CODE: HDY074B	CODE: HDY073B
							
CODE: HDY107A	CODE: HDY069C	CODE: HDY070B	CODE: HDY075A	CODE: HDY076A	CODE: EDY157B	CODE: EH3094A	CERAMIC EYELET
							
CODE: HDY065A	CODE: EDY098B	CODE: HDY066A	CODE: EDY261A	LEVER	GUIDE LEOVER	CODE: ADYF33B	CODE: ADY127A
							
LEVER	CODE: BDY145A	CODE: BDY111B	CODE: HDY037A	CODE: HDY037A	CODE: EDY244A	CODE: EDY184A	CODE: EDY252A







							
CODE: EDY253A	CODE: A2A184A		RIVET	HANGER	HANGER	MAGNET	HANGER
							
CODE: 047A	CODE: HDY041A	CODE: HDY040B	CODE: EDY068B	CODE: EDY029B	CODE: EDY030A	CODE: HDY 085A	CODE: HDY109A
							
CODE: A1A541A	CODE: A1A540A	CODE: HDY086A	CODE:VS10251	CODE: HDY022B	CODE: HDY055A	CODE: EDY208B	CODE: HDU056A
							
CODE: EDY236C	CODE: HDY105A	CODE: EDY150A	CODE: HDY083B	CODE: EDY237A	OIL PART	CODE: HDY036B	CODE: VJ12020
							
CODE: HDY024A	CODE: HDY023A	CODE: HDY048A	CODE: HDY043B	CODE: EDY266A	CODE: HDY016C	CODE: EDY042A	CODE: HSK056A






							
CODE: HDY098A	CODE: HDY111B	CODE: EDY121A	CODE: EDY099B	CODE: HR2012A	CODE: ADY218B	CODE: EDY264B	CODE: EDY239C
							
CODE: EDY059C	CODE: HDY044B	CODE: HDY032B	CODE: EDY045A	CODE: BDY117A	CODE: EDY042A	CODE: BDYF14B	CODE: HDY030D
							
CODE: HDY053A	CODE: HDY052A	CODE: A1A699A	CODE: HDY045A	CODE: HDY046A	CODE: HDY110A	CODE: EDY041A	CODE: EDY173A
							
CODE: EDY036B	CODE: A3A027C	CODE: EDY171B	CODE: A1A009A	CODE: EDY169A	CODE: EDY170A	CODE: EDY220A	CODE: HDY060A
							
CODE: A1A483B			CODE: HDY079A	CODE: HDY078A	CODE: VG13537	CODE: VG13510	CODE: VG13514



							
CODE: VG13505	CODE: VG13626		CODE: VG13577		CODE: BLBF31A	COUPLING	CODE: HH1468B
							
CODE: Z242018	CODE: EPS235A	FIXED CLAMP	FIXED CLAMP	CODE: EDN020A	BEARING SET	CODE: EDB084A	CODE: HDA067A
							
CODE: HD6032A	CODE: BNHF04H	CODE: HD0068A	HDF003A	CODE: HDA009A	CODE: HD6011A	CODE: BDCF05B	CODE: BLBF04A
							
CODE: HS9213A	COVER	CODE: EDN0198	CODE: EDN018B	CODE: HSH054A	CODE: HSH055A	CODE: ADHF01C	CODE: HQ5044B

							
CODE: EDH012A	CODE: BN7219B	CODE: BN7F33A	CODE: BN7F32A	CODE: BN7F31A	CODE: EMQ012C/013C	CODE: BDB203C	CODE: ALA697A
							
CODE: BMB207A	CODE: BDY036B	CODE: BDEF22A	CODE: A1A497	CODE: HDB051		CODE: HDB036A	
							
CODE: 0439011	CODE: BNDF03B	CODE: E201159	CODE: EDN016B	CODE: HDB100A		CODE: BDB126A	
							
CODE: EDVF06A	CODE: HS9144C	ESF017B	BEARING COVER	BEARING COVER	ARMATURE DISC	CODE: A1A699A	CODE: BM8105B

							
CLUTCH PART	CLUTCH PART	CODE: BDA1041	CODE: HLT005B	CODE: HDZ076B	CODE: HDP218A	CODE: HNF078A	CODE: EDC010A
							
CODE: BDY175B	CODE: ED9027A	CODE: BMB105B-1	CODE: BDVF08A	CODE: HA4039A		CODE: HDZ073B	LUBRICATING SEAT
							
CODE: HDF004A	CODE: HDA080B	CODE: A3A440A	COIL	CODE: HN7132	CODE: HN7194AA	GEAR SMALL	GEAR BIG
							
CODE:BDYF37B	CLAMP	SEPARATOR	RUBBER RING	BRACKET	CLAMP	OIL SEAL	LEFT RELEASER

							
WHEEL	CODE: EDN030B	CODE: BLT027A	CALMP	CODE: A1A726B	CODE: EPS214A	BUSHING	CODE: ADHF04B
							
THEMA 11E OPENER	SQUARE NUT	CODE: BLT207A	HOLDER	OPENER	CODE: AMQF09A	CODE: BDVF08A	HOOK
							
BRACKET	CODE: HDY074B	CODE: HDY009A	CODE: HDY073B	CODE: BLT202H	CODE: BLT206A, BLT205A	CODE: BLT201H	CODE: BLT202H
							
CODE: ALT103A	CODE: BLT108B	COVER	TRIANGULAR BLOCK	TRIANGULAR COVER	BRACKET	SHAFT	SCREW ROD

							
CODE: ADH202D				OPENER BOARD			
							
CODE: HN9217A		SCALE PLATE		SCALE PLATE SHAFT			
							
TENSIONING PIECE	TENSIONING PIECE	ROCKER ARM	CODE: BKY111B	LEVER	BRACKET	WEFT PLATE	CUTTER LEVER
							
HOOK	SCREW	CODE: A1A707A	CODE: A1A708A	CODE: EPS218A	SCREW FOR GUIDE HOOK	NUT FOR GUIDE HOOK	FIXED BLOCK

			
CODE: ELS002A		CODE: BDHF01A	
			
CODE: HN7125D		CODE: ADHF05B	
			
CODE: BN7F30A		CODE: EDH015C	
			
CODE: EHD1214A	CODE: ADHF03A	CODE: EH1213A	
			
CODE: EH1212A	FIXED STRIP	CODE: HN7138D	